



WIRESAGE

LIGHTNING EARPHONES
WITH BUILT IN MIC

User Manual and Warranty Info

Dear Customer,


Thank you for purchasing these Lightning Earphones with a built in microphone. We hope you spend countless hours using our earphones to enjoy high-quality music and hands free calling.

- Your Friends at WireSage

Product description

Name: C-EAR-L

Schematic Diagram



Functional Operations

1. Turning up the volume: Press and hold the volume + button continuously.
2. Turning down the volume: Press and hold the volume - button continuously.
3. Pausing the song: Click the multifunction button once while music is playing.
4. Advancing to the next song: Double-click the multifunction button while music is playing.
5. Going back to a previous song: Triple-click the multifunction button while music is playing.

Warranty Information

Covered by a 1 year warranty from the date of purchase.

What does this warranty cover?

Defects in materials and workmanship found in the product under normal use and service.

What does this warranty not cover?

This warranty does not cover damages due to transportation; dropping in water; improper use; failure to follow the product instructions; modifications; unauthorized repair; normal wear and tear; or external causes such as accidents, abuse, or other actions or events beyond our reasonable control

How to activate this warranty?

To activate your warranty, please email support@toporigins.com and include the original receipt to confirm proof of purchase, in addition to a brief explanation of your issue.

We recommend that you keep these earphones far away from magnets, electrical appliances, and other speakers.

Avoid placing the earphones in extreme temperatures.

Normal operating temperature range is 14°F to 104°F.

Avoid storing the earphones in a wet environment for a long time.

✉ info@toporigins.com

🌐 www.wiresage.com

☎ 855.622.5572

WIRESAGE™ is a **TopOrigins™** brand